



PAVERS



PATTERN PLAN




BRICK STONE HERRINGBONE PATTERN
RED RIVER HARDSCAPES CONCRETE PAVERS
BEGIN SETTING PAVERS ON THE SAND AT THE
LOWEST POINT OF THE AREA (IF THERE IS A
SLOPE) OR AT A SINGLE-CORNER STARTING
POINT. WALK ON THE PAVERS AS YOU LAY
THEM, NOT ON THE SCREEDED SAND.

FILL THE AREA WITH AN INTERLOCKING
PATTERN UP TO THE EDGE OF THE RESTRAINT.

CUT OUTER EDGE PAVERS TO FIT SNUGLY INTO
THE AREA. A SOLDIER COURSE OF PAVERS IS
RECOMMENDED.

SOLDIER COURSE PAVER BORDER

AXONOMETRIC




SPECIFICATIONS AND DETAILS FOR BASE
COMPACTION AND SUBSURFACE DRAINAGE ARE
SITE SPECIFIC AND SHALL PROVIDED BY CIVIL
ENGINEER/ GEOTECHNICAL.

FILL JOINTS W/ ASTM C-33 CONCRETE SAND
BRICK STONE HERRINGBONE PATTERN
RED RIVER HARDSCAPES CONCRETE PAVERS

1" SAND SETTING BED
6" COMPACTED STONE BASE FOR
RESIDENTIAL APPLICATIONS

8" FOR VEHICULAR APPLICATIONS
COMPACT IN 3" LIFTS
COMPACTED SUBGRADE
SEE SPECIFICATIONS

SECTION



BRICK STONE HERRINGBONE PATTERN
RED RIVER HARDSCAPES CONCRETE PAVERS

1" SAND SETTING BED
6" COMPACTED STONE BASE FOR
RESIDENTIAL APPLICATIONS

8" FOR VEHICULAR APPLICATIONS COMPACT
IN 3" LIFTS PLACE 1% SURFACE SLOPE
AWAY FROM ANY STRUCTURES
COMPACTED SUBGRADE
SEE SPECIFICATIONS

Red River Hardscapes

Brick Stone Pavers .HERRINGBONE PATTERN