



PAVERS



PATTERN PLAN



BRICK STONE BASKETWEAVE PATTERN
RED RIVER HARDSCAPES CONCRETE PAVERS


BEGIN SETTING PAVERS ON THE SAND AT THE LOWEST POINT OF THE AREA (IF THERE IS A SLOPE) OR AT A SINGLE-CORNER STARTING POINT. WALK ON THE PAVERS AS YOU LAY THEM, NOT ON THE SCREEDED SAND.

FILL THE AREA WITH AN INTERLOCKING PATTERN UP TO THE EDGE OF THE RESTRAINT.

CUT OUTER EDGE PAVERS TO FIT SNUGLY INTO THE AREA. A SOLDIER COURSE OF PAVERS IS RECOMMENDED.

SPECIFICATIONS AND DETAILS FOR BASE COMPACTION AND SUBSURFACE DRAINAGE ARE SITE SPECIFIC AND SHALL PROVIDED BY CIVIL ENGINEER/ GEOTECHNICAL.

AXONOMETRIC



FILL JOINTS W/ ASTM C-33 CONCRETE SAND

BRICK STONE BASKETWEAVE PATTERN
RED RIVER HARDSCAPES CONCRETE PAVERS


1" SAND SETTING BED

6" COMPACTED STONE BASE FOR RESIDENTIAL APPLICATIONS

8" FOR VEHICULAR APPLICATIONS
COMPACT IN 3" LIFTS

COMPACTED SUBGRADE. SEE SPECIFICATIONS

SECTION



BRICK STONE BASKETWEAVE PATTERN
RED RIVER HARDSCAPES CONCRETE PAVERS

1" SAND SETTING BED

6" COMPACTED STONE BASE FOR RESIDENTIAL APPLICATIONS

8" FOR VEHICULAR APPLICATIONS
COMPACT IN 3" LIFTS PLACE 1% SURFACE SLOPE AWAY FROM ANY STRUCTURES

COMPACTED SUBGRADE. SEE SPECIFICATIONS

Red River Hardscapes Brick Stone Pavers . BASKETWEAVE PATTERN

