



PAVERS




PATTERN PLAN




ROMAN ROAD PATTERN B RED RIVER HARDSCAPES CONCRETE PAVERS
 BEGIN SETTING PAVERS ON THE SAND AT THE LOWEST POINT OF THE AREA (IF THERE IS A SLOPE) OR AT A SINGLE-CORNER STARTING POINT. WALK ON THE PAVERS AS YOU LAY THEM, NOT ON THE SCREEDED SAND.
 FILL THE AREA WITH AN INTERLOCKING PATTERN UP TO THE EDGE OF THE RESTRAINT.
 SPECIFICATIONS AND DETAILS FOR BASE COMPACTION AND SUBSURFACE DRAINAGE ARE SITE SPECIFIC AND SHALL PROVIDED BY CIVIL ENGINEER/ GEOTECHNICAL.

AXONOMETRIC



ROMAN ROAD PATTERN B RED RIVER HARDSCAPES CONCRETE PAVERS
 FILL JOINTS W/ ASTM C-33 CONCRETE SAND
 1" SAND SETTING BED
 6" COMPACTED STONE BASE FOR RESIDENTIAL APPLICATIONS
 8" FOR VEHICULAR APPLICATIONS
 COMPACT IN 3" LIFTS
 COMPACTED SUBGRADE
 SEE SPECIFICATIONS

SECTION



ROMAN ROAD PATTERN B RED RIVER HARDSCAPES CONCRETE PAVERS
 1" SAND SETTING BED
 6" COMPACTED STONE BASE FOR RESIDENTIAL APPLICATIONS
 8" FOR VEHICULAR APPLICATIONS COMPACT IN 3" LIFTS
 PLACE 1% SURFACE SLOPE AWAY FROM ANY STRUCTURES
 COMPACTED SUBGRADE
 SEE SPECIFICATIONS

Red River Hardscapes
 ROMAN ROAD . PATTERN B

